

# USER GUIDE

(Version 1.0)

Identix, Inc. Av. Ipanema 165 – CJ115/116 Bairro Empresarial 18 Do Forte Barueri, SP CEP 06471-002 Brazil +55 (11) 4193-1220 www.idntx.com





# SOFTWARE RELEASE 1.0.0.32

# Table of Contents

Introduction
Supported Impinj Hardware and Firmware releases2
Installing CONNECTIX on your Impinj Reader
Install the CONNECTIX software via the Octane Web interface
Access the CONNECTIX License and Configuration screen
Configuring CONNECTIX for Impinj
Reader Settings
RAIN RFID Settings
Advanced GPO Settings
Triggers Settings
Output Data Formatting and Filtering
Data Output Options
MQTT
Local Socket Server
HTTP Post
Serial Port10
Keyboard Emulation10
USB Flash Drive10
Removing and Stopping CONNECTIX from the Impinj Reader11
Notices
Trademaks12





# Introduction

Identix CONNECTIX for Impini is an on-reader software that enables users to easily set configurations for a single Speedway reader or gateway, and quickly access RAIN RFID data. The easy-to-use graphical user interface facilitates setting up reader configurations to quickly read tag data such as EPC, TID and User Memory, and record other relevant information such as last seen Timestamp and Antenna ID. Multiple protocols are provided for passing RAIN RFID data to an application without costly software development or middleware expenses. Identix CONNECTIX provides a simple user interface and reader configuration for your RAIN RFID infrastructure deployment.

#### FEATURES

- Easy-to-use graphical user interface for deployments of single readers used to identify RAIN RFID
- Tag Data (EPC, User Memory, and TID)
- Set basic reader configurations to read RAIN RFID tags and save the configuration on-reader
- Access RAIN RFID data in an application via MQTT, HID, HTTP POST, TCP/IP, Serial, or USB protocols
- On reader parsing of SGTIN-96 to different GTIN formats
  - o GTIN14
  - o GTIN13
  - o GTIN12

# Supported Impinj Hardware and Firmware releases

Identix Connectix embedded software applications support the following Impinj UHF RFID readers and gateways:

- IPJ-REV-R120 all configurations (including the Antenna Pack option)
- IPJ-REV-R220 all configurations
- IPJ-REV-R420 all configurations (including Antenna Hub)
- IPJ-REV-R640 all configurations
- IPJ-REV-R660 all configurations
- IPJ-REV-R680 all configurations

All Octane firmware releases after 5.8 (included) are supported

## Installing CONNECTIX on your Impinj Reader

## Install the CONNECTIX software via the Octane Web interface

1. First download the Connectix for Impinj software from <a href="https://idntx.zendesk.com">https://idntx.zendesk.com</a> and place it in a location on your PC





2. Enter the Impinj Octane Reader Web Interface. Under "Reader Upgrade" section "Select Upgrade File" choose the Connectix for Impinj software file you downloaded to your PC

← → C	192.168.10.40/cgi-bin/ind	dex.cgi		☆ 【	] 6 0
* Bookmarks	s 🗅 SPAM 峰 Translate [	Trello 🗞 DNS 🗋 BackupDNS 🔀 Wix	🗾 ConstContact 🔁 Zoho 🧿	RackSpace 🚛 Zendesk 🛛 🔹 📙	Other bookma
				_	
					-
	17		UL AUTOPU OT	the second se	
			ILA AUTOFILUT	a martine	
	<b>3</b> F	PEEDWAY		impinj.	
	the forthe to	REVOLUTION		and the second se	
		1021 201			
	READER		READER UPGRADE		
	Reader Name	SpeedwayR-10-23-BC	Upgrade Status	Ready	
	Uptime	0 Days, 0 hours, 13 minutes, 47 seconds	Last Operation Status	Waiting for manual reboot	
	System Time	Sun Jun 18 08:11:36 UTC 2017	Select Upgrade File	Choose File No file chosen	
	LLRP Status	Disconnected	Upgrade Now	Upgrade	
	RFID Status	Idle			
			CHANGE REGULATORY	REGION	
			Available Regions	Brazil 902-907 and 915-928 MHz V	
	DETAILS		Press to Update	Update	
	Model Name	Considerate P.420			
	Regulatory Region	Brazil 902-907 and 915-928 MHz	ANTENNA HUB		
	MAC Address	00:16:25:10:23:BC	Feature Status	Disabled	
	Software Version	5.2.1.240	Press to Enable	Enable	
	Hardware Version	250-002-003			
	Serial Number	370-09-25-0041	READER REBOOT		
			Reboot Status	Ready To Reboot	
			Press to Reboot	Reboot	
	NETWORK		OUTCKLINKS		
	TR Address	102 169 10 40	QUICK LINKS		
	Network Mask	255.255.0.0	sunnort impini.com	1	
	HCCWOIR LIUSK	233.233.0.0	Speedurer Installation S. One	rations Guide	
	Default Route	192,168,0,1			
	Default Route Broadcast Address	192.168.0.1 192.168.255.255	Third party software licenses		

the second se		n - na manana ang ang ang ang ang ang ang ang an						
ganize 👻 New	folder						855 <b>*</b>	(
🔮 Documents 📝	• • •	Vame	Date modified	Туре	Size			
🖁 mauricio 🛛 🖈		Connectix-IPJ-1.0.0.31.upg	21/08/2017 17:50	UPG File	4.73	7 KB		
🔜 Desktop 🛛 🖈		octane_5_12_0_240.upg	21/08/2017 18:39	UPG File	15.61	7 KB		
👥 Identhis 🛛 🛪								
👥 Identix 🛛 🖈								
📙 Impinj 🛛 🚿								
🔒 RFID 🛛 🖈								
🚽 OfficeWork  🖈								
📕 Work-MS 🛛 🦼								
This PC 🖌								
Dropbox								
OneDrive								
This PC								
External Backun	ar 🖌							
5	File name	Connectiv-IPI-10021 upg				All Fil	er.	

3. Once you choose the correct ".UPG" file proceed with the installation of Connectix for Impinj software as if you were upgrading the firmware on the Impinj reader. The reader can take up to three minutes to unpack and install all necessary files. Let the reader finish the installation and then proceed with a re-boot of the reader.





## Access the CONNECTIX License and Configuration screen

To access the CONNECTIX configuration screen, please open a web browser providing the following address for the connection <u>http://MySpeedwayReader:8080</u> where MySpeedwayReader represents the IP address or hostname of your Speedway reader. The default username and password for accessing the configuration screen are: "admin" and "admin".



CONNECTIX software requires a valid license to run. Without a valid license CONNECTIX will be limited to 500 reads

To obtain a license for you reader please contact Identix sales: sales@idntx.com

Once you get a valid license, please copy/past it into the License field and click "apply settings".

# Configuring CONNECTIX for Impinj

#### Reader Settings

On this section, you will configure the reader operating mode, transmission power and GPIO settings.





#### **RAIN RFID Settings**

Here you can configure RAIN RFID related settings such as RF operating mode, inventory mode, target sections, tags population estimate and transmission power for each individual antenna.

	identhis   🗆 🗙	< (••) R	eader Sei 🗙 🗸	🗊 LP: F	athon	×	e - Ic 🗙 🗸	+ Identix X		+ Identix	×	GID	_			×
←	$\rightarrow$ C (	192.168	<b>.10.40</b> :8080								7	☆		8	٥	:
		2														1
	Home	Reade	er Settings	Data 1	ormat	Data out	put optior	ns Actions								
	RAIN F	RFID	Settings	6												
	RF Mode:															
	AutoSet	DenseRe	eader						•							1
	Target:															
	Dual Tar	get							•							
	Session:															
	0								•							
	Tag Popula	ation Est	timate:													
	32															
	Antenna E	Enabled	Tx Power R	x Sens	itivity	Connection	Status	Current Tx Powe	er							
	1		30,00 •	-70	•	(by		0								
	2	1	30,00 •	-70	•	(cy)		0								
	3	1	30,00 •	-70	Ŧ	(cy)		3000								
	4	-	30,00 •	-70	Ŧ	(hy)		3000								

Important! CONNECTIX will automatically identify the reader model and the total number of antennas. For instance, if you have a Speedway R420 with 02 Antenna Hubs, there will be 18 ports available for configuration on this screen. For the Impinj gateways, you will be able to configure each beam state individually.





## Advanced GPO Settings

Here you can configure how the reader GPOs will behave.

	identhis   X (•) Reader Se X (=) LP: Fathor X   Device - Ic X + Identix X + CONNECT X + Identix	Mauridio ×	-			×
÷	→ C ① 192.168.10.40:8080	₽☆		6	0	:
	Advanced GPO					•
	Advanced GPO Enabled					
	GPO Port 1:					
	Normal					
	GPO Port 2:					
	Normal					
	GPO Port 3:					
	Normal					
	GPO Port 4:					
	Normal					
						-

The following conditions can trigger a GPO change based on the following statuses

- Reader Operation Status
- LLRP connection status
- Reader inventory status
- Network Connection Status
- Reader Inventory Tag Status





## Triggers Settings

## Here is where you can configure GPI triggers to start/stop inventory based on external sensors.

identhis III X (w) Reader Se X 🖨 I P: Fathor, X 🕞 Device - III X 👎 Identiv - X 🗣		deuridio	-			×
→ C ① 192.168.10.40:8080		¶☆		6	0	
Triggers			,			
Start Trigger:						
Immediate	¥					
Start Trigger GPI Port:						
1	*					
Start Trigger period in miliseconds:						
0						
Start Trigger GPI Event:						
Low	Y					
Stop Trigger:						
None	v					
Stop Trigger duration in miliseconds:						
0						
Stop Trigger GPI Port:						
Disabled	T					
Stop Trigger GPI Event:						
Low	•					
Keenalive						
Enabled Keenalive inverval in seconds:						
Apply Setting	IS					





## Output Data Formatting and Filtering

Here you configure how the collected information will be formatted. Identix CONNECTIX can include basic information such as EPC data, antenna port information, timestamp, RSSI and TID.

_	idanthir I. Y. (a) Pandar So. Y. C. D. Esthor. Y. E. Davira, J. Y. E. Idantiv. Y. E. CONNECT. Y. E. Idantiv.	Meutido	-		1	×
2		^		6	•	:
-	7 0 0 152.100.1040.0000	μ I		G	Ĩ	•
	ICENTIX CONVECTOR					Î
	Home Reader Settings Data format Data output options Actions					1
	Fields to include:					
	Parse SGTIN-96 to GTIN					
	GTIN14					
	O GTIN13					
	GTIN12					
	🗹 Antenna Port					
	✓ Timestamp (EPOCH in useconds)					
	✓ RSSI					
	Format:					
	Field Delimiter:					
	Comma					
	Line Ending:					
	CRLF					
	Reader Name / Device ID:					
	NqCxL:xSpanDemo					
						-

Optionally CONNECTIX can convert SGTIN-96 encoded data into GTIN formats automatically on-thefly. Please choose the desired formatting, along the delimiters that will be used for separating each field.





CONNECTIX can also apply software and hardware filters to lower network traffic and avoid readings of undesired tags.

	identhic I X (n) Reader Se X 🖨 I P. Fathor X E Device , I X F Identiv X F CONNECT X F Identiv X		-			×
_		Ş		a	•	:
				9	-	•
	Software Filter:					
	□ Filter Reports by interval					
	Report inverval in seconds:					
	1					
	Group by:					
	EPC v					
	RAIN RFID Filter					
	Gen2 Filter					
	Gen2 Filter Bank:					
	EPC					
	Gen2 Filter Bit Pointer:					
	0					
	Gen2 Filter Mask:					
	АААА					
	Gen2 Filter Lenght:					
	16					
	Apply Settings					

## Data Output Options

Identix CONNECTIX can send the collected information automatically to one or more destinations via different protocols and methods configured under this section.

#### MQTT

MQTT is a popular, high efficiency, low latency IoT oriented network protocol offered on popular IoT platforms such as Microsoft Azure, Amazon AWS, IBM Bluemix, Google Cloud and many others.

With MQTT you can connect you Speedway readers to cloud platforms in a matter of minutes. Just enter the connection information on this section and you are ready to go.

#### Local Socket Server

Selection this option, CONNECTIX will send the tags information to a local sockets server available inside the speedway reader.

#### **HTTP Post**

If you want to send the read data directly to a web server, you can configure the HTTP post information for you service here.





## Serial Port

CONNECTIX will output the collected information on the reader serial port if you select this option.

#### Keyboard Emulation

CONNECTIX will output the collected information on the USB port, behaving like a keyboard if you select this option.

#### USB Flash Drive

CONNECTIX will write the collected information on a USB stick connected to the reader USB port if you select this option.

						Maur	do	_		]	
identhis	× (••) Reader Set ×	🟮 LP: Fathon 🗙	Device - Ic 🗙	+ Identix ×	× + Identix	×					
$\rightarrow$ C	Not secure   192.16	5 <b>8.10.40</b> :8080				7	☆		6	0	
_											Ī
iden											
Hom	e Reader Settings	Data format	Data output optio	ons Actions							
MQ	ГТ										
🗆 Enal	ble										
Broker	Address:										
mqtt:	//201.87.143.170										
Broker	Port										
	i ort.										
1883											
Topic:											
NqC	kL/xSpanDemo/inventory	1									
Device	ID:										
NaCo	d :xSnanDemo										
1190											
Broker	Username:										
NqC	kL:xSpanDemo										
Broker	Password:										





	identhis     × 🗰 Reader Se 🗴 🖨 LP: Fathor: × 🕞 Device - I: × 🛨 Identix - × 🛨 CONNECT × 🛨 Identix - ×	Maurit	i0	-			×
←	→ C ③ Not secure   192.168.10.40:8080	Ţ	☆		6	٥	:
	Local socket server						*
	Enable						
	Socket Port:						
	14150						
	HTTP POST						
	Enable						
	Data Format						
	PLAIN v						
	Remote Server URL:						
	http://posttestserver.com/post.php						
	POST interval in seconds:						
	1						
	Serial Port						
	Enable						
	115200						
	Keyboard emulation						
	Enable						
	USB Flash Drive						
	Enable						
	Apply Settings						-

## Removing and Stopping CONNECTIX from the Impinj Reader

You can temporarily stop CONNECTIX or remove it permanently from the Speedway reader if you wish. To temporarily deactivate CONNECTIX, just press "stop". To permanently remove it from the Speedway reader, hit the "Uninstall Connectix" button.





0 identix	× ((•) Reader Settings ×	Mautidio	- <u></u>	C	]	×
$\leftrightarrow \Rightarrow G$	① 192.168.10.40:8080	☆		6	0	:
	identix CONNECTER					
	Home Reader Settings Data format Data output options Actions Application Current Status:					
	STARTED					
	Stop					
	Click the button below to retrieve the reader logs: Get reader logs					
	Click the button below to remove the application from the reader: Uninstall Connectix - version 1.0.0.31					
🗋 octan	2_5_12_0_240.upg			Show	all	×

#### Notices

#### Notices: Copyright © 2015, Identix RFID, Inc. All rights reserved.

Identix gives no representation or warranty, express or implied, for accuracy or reliability of information in this document. Identix reserves the right to change its products and services and this information at any time without notice. EXCEPT AS PROVIDED IN IDENTIX'S TERMS AND CONDITIONS OF SALE (OR AS OTHERWISE AGREED IN A VALID WRITTEN INDIVIDUAL AGREEMENT WITH IDENTIX), IDENTIX ASSUMES NO LIABILITY WHATSOEVER AND IDENTIX DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATED TO SALE AND/OR USE OF IDENTIX PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY PATENT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT IS GRANTED BY THIS DOCUMENT. Identix assumes no liability for applications assistance or customer product design. Customers should provide adequate design and operating safeguards to minimize risks. Identix products are not designed, warranted or authorized for use in any product or application where a malfunction may reasonably be expected to cause personal injury or death or property or environmental damage ("hazardous uses") or for use in automotive environments. Customers must indemnify Identix against any damages arising out of the use of Identix products in any hazardous or automotive uses.

## Trademaks

Identix RFID is a trademark or registered trademark of Identix RFID Inc.

All other product or service names are trademarks of their respective companies.